



SHIFTBASE1 (Mk1 Chassis)

Installation Instructions

1. Remove your existing shifter assembly and rod.
2. Remove the small snap ring from the top of the spring tensioner.
3. Remove the white plastic retaining ring, spring, and old plastic ball assembly.
4. Slide one Delrin bushing down the shifter shaft. (Image 1).

1



5. Slide complete shifter assembly down rod and insert bottom bushing into the bottom of the bearing (image 2).

2



6. Slide a second Delrin bushing down rod and insert into the top of bearing (Image 3).

3



7. Slide the spring and white plastic retainer down shaft and follow with the small snap ring (Image 4).

8. Slide Delrin set screw collar down shift rod and secure tightly in place above the small snap ring with a 3mm Hex key. (The set screw collar is tight but it will fit down the shaft with some effort.) (Image 4).

4



9. Re-install the complete assembly in your car and adjust the shifter per factory recommendations.